




MB MASONRY BRIDGE SAW PARTS LIST





MODELS:

MB65, MB100, MB120 & MB150

SPARE PARTS DIAGRAM





PART NO.**PART DESCRIPTION**

GM01	STARTER ASSEMBLY 110V
GM01A	STARTER ASSEMBLY 220V
GM01B	STARTER ASSEMBLY 415V
GM02	HANDLE
GM03	STARTER PLATE
GM04	HANDWHEEL & GRIP
GM05	BEARING
GM06	FEED SCREW
GM07	MOTOR CONSOLE
GM08	MOTOR 110V
GM08A	MOTOR 220V
GM08B	MOTOR 415V
GM09	INNER COLLAR
GM10	OUTER COLLAR
GM11	NUT – BLADE SHAFT
GM12	WATER HOSE
GM13	LINEAR BEARING
GM13A	SEAL
GM14	HEAD CONSOLE
GM15	WELDED FRAME (WATER TRAY)
GM16	BEAM SET (PAIR) MB100
GM16A	BEAM SET (PAIR) MB65
GM16B	BEAM SET (PAIR) MB120
GM16C	BEAM SET (PAIR) MB150
GM17	STOP RING
GM18	BEAM HOLDER
GM19	BRACKET L/H
GM19A	BRACKET R/H
GM20	ANGLE ADJUSTER
GM21	LOCKING HANDLE
GM22	PIVOT AXLE
GM23	WATER PUMP
GM24	LEG LOCKING SCREW
GM25	LEG (SQUARE TYPE)
GM25A	LEG (L SHAPE)
GM26	TRANSPORT HANDLE
GM27	CAPACITOR
GM28	TABLE TOP (PAIR)
GM29	BACK GUIDE (PAIR)
GM30	GUIDE A CUT
GM31	LOCK SCREW
GM32	BLADE GUARD ASSEMBLY
GM33	COVER – BLADE GUARD
GM34	LOCKING SCREW – BLADE GUARD
GM35	WATER FEED
GM36	WATER TAP
GM37	FAN COVER
GM38	DRAIN BUNG
GM39	SPLASH RUBBER
GM50	MOTOR & STARTER ASSEMBLY 110V