

WEHIRE
SURFACE PREPARATION
EQUIPMENT
TEL 01633 619129

CONNECTING 3PHASE MAINS SUPPLY TO IMPACT S210E-40R BLAST MACHINE AND 3 PHASE DUST CONTROL



TAIL ADAPTOR MAY BE USED TO CONNECT TO 63AMP SOCKET AND GIVE 32AMP CONNECTION OR MAY BE DIRECT CONNECTION



WALL SOCKET 3 PHASE MAINS SUPPLY NEEDS TO BE 5 PIN 32AMP OUTLET



PHASE INVERTER PLUG FITTED

TO DUST CONTROL TO TURN PHASE

ROTATION AND CHECK AGAINST ARROW ON SIDE OF MACHINE



3 PHASE 415V 32AMP 5 PIN EXTENSION LEADS 15M LONG

UP TO MAX 4 LEADS TO CONNECT TO THE DUST CONTROL UNIT

DUST CONTROL CONNECTS TO THE INCOMING 3 PHASE SUPPLY



IMPACT S210-40R
 FRONT SECTION
 BLAST UNIT

CONNECT FROM FRONT SECTION TO THE POWER TAKE OFF PORT ON THE DUST CONTROL

HOSE CONNECTS FROM DUST CONTROL TO FRONT SECTION



3PHASE DUST COLLECTOR