

W E H I R E
S U R F A C E P R E P A R A T I O N
E Q U I P M E N T
TEL 01633 619129

WALL SOCKET
 3 PHASE MAINS
 SUPPLY
 NEEDS TO BE
 5 PIN 32AMP
 OUTLET



TAIL ADAPTOR MAY BE USED
 TO CONNECT TO 63AMP
 SOCKET AND GIVE 32AMP
 CONNECTION OR MAY BE
 DIRECT CONNECTION



3 PHASE 415V 32AMP 5 PIN
 EXTENSION LEADS,
 UP TO MAX 4 LEADS



DUST CONTROL
 CONNECTS TO THE
 INCOMING 3 PHASE
 SUPPLY



HOSE CONNECTS
 FROM DUST CONTROL
 TO GRINDER



INTERMEDIATE CABLE
 CONNECTS GRINDER
 TO DUST CONTROL



**CONNECTING 3 PHASE BEF 320 SCABBLER TO MAINS
 SUPPLY FROM WALL SOCKETS IN FACTORY
 VIA 3 PHASE DUST CONTROL**



PHASE INVERTER PLUG FITTED
 TO BOTH ITEMS TO TURN PHASE
 ROTATION TO MATCH THE ARROW ON FAN
 GUARD SO HYD DRIVE WORKS



**HYD DRIVE SYSTEM WILL ONLY WORK WHEN THE 3PHASE MOTOR RUNS THE CORRECT WAY SO DRUM CUTS THE
 CORRECT WAY . IF YOU HAVE NO HYD DRIVE CHECK AND CHANGE THE PHASE ROTATION AS ABOVE PICTURE**